



1 需要安装的软件




2 需要用到的程序





3 测试环境设置（电脑本地链接属性设置）



4 测试步骤





Modbus Poll - [Mbpoll2.mbp]

File Edit Connection Setup Functions Display View Window Help

Tx = 1516: Err = 0: ID = 2: F = 03: SR = 50ms

	00000	00010	00020	00030	00040	00050	00060	00070	00080
0	80	90	100	110	120	130	140	150	160
1	81	91	101	111	121	131	141	151	161
2	82	92	102	112	122	132	142	152	162
3	83	93	103	113	123	133	143	153	163
4	84	94	104	114	124	134	144	154	164
5	85	95	105	115	125	135	145	155	165
6	86	96	106	116	126	136	146	156	166
7	87	97	107	117	127	137	147	157	167
8	88	98	108	118	128	138	148	158	168
9	89	99	109	119	129	139	149	159	169

